

- 1. Buffer base should be made of two thicknesses of 3/4" plywood 3. The holes are 5/16" thru, all slots are 5/16" x 1" long thru. laminated together for an overall thickness of 1-1/2".
- 2. The edges should be rounded over for safe and comfortable handling.
- **4.** All counterbores and enlarged slots are 3/4" dia. x 1/2" deep, holes and slots with dashed lines are machined on the back side.

