FLOYD ROSE® SADDLE INSTALLATION INSTRUCTIONS

Correct string radius is achieved using three saddle heights. Saddles are numbered (on the bottom of each saddle). 1 (lowest height), 2 (middle height) and 3 (highest), and shoud be installed in the following order:



- 1. Insert string end in hole at base of string block cavity.
- 2. GENTLY tighten screw until it just touches the string.
- 3. Tighten with allen key an additional 1/4 TURN ONLY.

CAUTION: Excessive tightening is not required to keep string in place. Overtightening screw may crack the housing and void your warranty.

> This product has a one year warranty against manufacturing defects This does not cover wear and tear from use.