

Golden Age Pre-wired Harness for P Bass[®]

Follow these steps to wire up your bass

Congratulations!

You're about to upgrade your bass' electronics by making only a few connections. Thanks for choosing our Golden Age Harness, which we hand soldered here in our Ohio shop.

If you're new to soldering, we have free information that will help you: search "how to solder" at stewmac.com.

Check the holes on your pickguard: do the new controls fit? These are standard sizes, but some unusual pickguards have been drilled for smaller parts. These standard control pots and jack require 3/8" holes.

STEP 1 Ground the pickup to the volume control

Solder the ground wire from the pickup to the back of the Volume pot.

STEP 2 Connect the pickup lead wire

Solder the lead wire from the pickup to the bottom lug of the Volume pot.

STEP 3 Connect the ground wire

Thread the ground wire through the access hole in the control cavity to the bridge and tighten the bridge down onto it. This tight contact with the bridge plate forms the ground connection, requiring no solder.

Reattach your pickguard, and you're done!

Save the wooden template. It's a useful tool for holding parts in position during future wiring jobs.

