



Add two new sounds to your Telecaster

To support StewMac Trade Secrets video #340

Updated 9/27/19

Here's how to give your Fender Telecaster additional sounds to make it a lot more versatile.

Before

Standard Tele wiring consists of two single-coil pickups and two control knobs: Tone and Volume.

A three-way switch gives you these three options:

- **Neck pickup** (warm, mellow)
- **Both pickups** wired in parallel
- **Bridge pickup** (bright, aggressive)

After

The five-way Super Switch adds two more options:


- **Humbucking, wired in series** (rich humbucker tone and noise reduction)
- **Humbucking, out-phase** (bright, nasal-sounding)

This wiring requires a separate ground lead for the neck pickup's metal cover. Many Tele neck pickups already have this third lead. If yours doesn't, watch the video to see Paul show you how to add one.


Watch the video at stewmac.com **ts340**

Watch Paul show you how in our free Trade Secrets video #340. Search **ts340** at stewmac.com.

Before Standard modern Telecaster wiring with 3-way switch



After Modified with the 5-way Oak Grigsby Super Switch



Oak Grigsby Super Switch

This 4-pole, 5-way lever switch has six lugs per pole, for virtually limitless pickup and coil selection options.

StewMac #3200

You'll find more mods using this switch at stewmac.com.

