





SCAN TO WATCH THE INSTRUCTIONAL VIDEO:



INSTRUCTIONS FOR PACKING ELECTRIC GUITAR WITH CASE OR GIG BAG

WHAT'S IN THE KIT:



Guitar shipping boxes (folded)



Center box reinforcement beams



Bag containing inflatable <u>bottom wraps</u>

ТОР		1
-	\rightarrow	

Bag containing inflatable <u>top hats</u> Also includes bottom end caps for <u>rectangular case</u>*

AERIS LIMITED WARRANTY

Aeris warrants that its products will be free from defects from the date the product is received by the purchaser for a period of six (6) months. No other express warranty is given, and no affirmation of Aeris or its representatives, by words or action, shall constitute a warranty. Purchaser's sole and exclusive remedy shall be limited to the replacement of any defective product during the warranty period or credit the value of any defective products at the sole discretion of Aeris. The warranty will be void if you fail to follow the instructions for packing as contemplated herein. You acknowledge and understand that Aeris, its representatives and/or distributors are not responsible in any way for any liability, damage or loss incurred to the user or any musical instruments while using Aeris inflatable products during the shipping process.

PREPARE THE BOX

Unfold the guitar shipping box, and tape the bottom flaps. Stand it up, leaving the top open.



3

С

Start

here

2 INFLATE

Inflate 1 top hat and 1 bottom wrap*.



FILL THE BOX FROM THE BOTTOM UP ISTART AT STEP A1:

Lastly, insert the inflated top hat.

Third, fold the center box beam along the score marks. Passing the top of the guitar case through the center opening, lower the beam into the box. It will rest on the shoulders of the case.

Second, align the guitar case in the center of the bottom wrap, and slowly lower it into the bottom of the box. Verify that the bottom wrap surrounds the base and sides of the case's lower portion.

First, place the inflated bottom wrap* flat along the opening of the box, and slightly push down the middle so that the center of the wrap is just inside the box, but the sides are resting up outside the side edges of the box.

TAPE THE BOX CLOSED

It is possible that the top hat may protrude slightly from the top of the box. It was purposely designed this way in order to compress the contents when the box is closed and taped shut.

Your valuable guitar is now secure and ready to ship!





INFLATION TIPS

Aeris inflatable materials are identified with either a clear plastic tab (with green arrow), or a plastic inflation coupler at the valve entrance. the printed blue arrows on the filling valve determine the direction of the air.

There are several ways to inflate Aeris inflatable materials:

USING THE AERIS AIR-FILLING KIT

Follow the directions supplied with the kit.

USING AN AIR COMPRESSOR

Aeris inflatable materials are designed to inflate with a maximum air pressure of 12 PSI. Most compressors are designed to generate between 125 and 150 PSI and the gauges are not calibrated to dial down to 12 PSI.

For those who will be using a compressor (that cannot be easily adjusted to 12 PSI), we STRONGLY recommend the use of the Aeris Inflation Kit. This is a multi-piece accessory that can be adjusted down to 12 PSI, and uses a foot pedal to activate the air flow.

MANUAL INFLATION

For lower volume users, a standard bicycle or balloon pump can also be used. This method requires physical effort and takes considerably longer. Inflate until the device is rigid but not overly hard.

NOTE

Some chambers may not inflate immediately - in this case, simply knead the fill valves to allow the air into the chambers.

RECTANGULAR CASES

If packing a rectangular case, simply replace the bottom wrap by the inflated bottom end caps for rectangular case.

After inflating - flip it INSIDE OUT:



ready to insert the case into it.